

PL**Power bank 80000 mAh**

TRABAT47826 PRIME-V8

tracer®**Gniazda wejścia/wyjścia:**

Moc znamionowa: 296Wh

Napięcie nominalne:

Wejście: TYPE-C1 5V/3A, 9V/2.22A, 12V/1.67 (max PD20W)

Wejście: TYPE-C2 5V/3A, 9V/2.22A, 12V/1.67 (max PD20W)

Wyjście: USB-A1 5V/3A, 9V/2.0A, 12V/1.5A, SSCP10V2.25A (QC22.5W)

Wyjście: USB-A2 5V/3A, 9V/2.0A, 12V/1.5A, SSCP10V2.25A (QC22.5W)

Wyjście: USB-A3 5V/3A, 9V/2.0A, 12V/1.5A, SSCP10V2.25A (QC22.5W)

Wyjście: TYPE-C1 5V/3A, 9V/2.22A, 12V/1.67A (max PD20W)

Wyjście: TYPE-C2 5V/3A, 9V/2.22A, 12V/1.67A (max PD20W)

80000mAh QC22.5W + PD20W

Typ chemiczny akumulatora: Li-Ion (litowo-jonowa typ pouch) 3.7V

Waga produktu: 1560g

SN: 11/25

Akumulator ładowalny

Typ przenośny

1. Przed pierwszym ładowaniem postaraj się w pełni rozładować power bank. Pomocze to skutecznie skalibrować wskazania poziomu naładowania urządzenia. Proces taki najlepiej przeprowadzić 2-4 razy.
Do ładowania power banków używaj odpowiednich akcesoriów tj. ładowarki oraz kabla. Ładowarka powinna być co najmniej o mocy 2A. Im mocniejsza ładowarka 18W, 20W, 24W, 30W tym skuteczniej i szybciej naładuje baterię. Ważny jest też kabel do ładowania. Pamiętaj, że nie każdy kabel służy do ładowania, większość służy do przenoszenia danych.
 2. Celem sprawdzenia poziomu naładowania akumulatora naciśnij przycisk. Ilość diod/cyfra na ekranie pokaże poziom akumulatora.
 3. Jeżeli produkt posiada funkcję tzw. szybkiego ładowania in/out, jedna z diod podczas szybkiego ładowania świecić będzie innym kolorem niż pozostałe. Jeżeli akumulator posiada ekran, podczas szybkiego ładowania in/out pojawi się ikona.
 4. Aby skutecznie naładować urządzenie należy podłączyć kabel z odpowiednią końcówką do jednego z gniazd „wejścia”.
- Aby skutecznie naładować odbiornik np. telefon, należy połączyć kabel ładowania z jednej strony do jednego z gniazd „wyjścia” akumulatora, natomiast drugą wtyczkę kabla do gniazda urządzenia, które chcemy naładować.

INFORMACJA DOTYCZĄCA BEZPIECZEŃSTWA / ŚRODKÓW OSTROŻNOŚCI :

1. Przenośny powerbank posiada wysokiej jakości ogniwo akumulatorowe, które gwarantuje wygodne i długie użytkowanie.
2. Sugeruje się, aby użytkownik używał standardowego zasilacza o napięciu wyjściowym DC 5V.
3. Jeżeli występuje zjawisko puchnięcia baterii, widąc wypukłość na obudowie, należy bezwarunkowo zaprzestać użytkowania produktu i natychmiast skontaktować się z serwisem.
4. Nie rzucać urządzenia, nie otwierać obudowy, nie demontować elementów obudowy, nie narażać urządzenia na przebiecie. Nie narażać na działanie ognia, wysokich temperatur oraz wilgoci i wody.
5. Zaleca się okresowe ładowanie urządzenia (co najmniej raz na 4 miesiące), aby zachować żywotność ogniw baterijnych.

Ostrzeżenie. Należy postępować zgodnie z powyższymi instrukcjami bezpieczeństwa, w przeciwnym razie urządzenie może spowodować pożar, wybuch bądź inne szkody.



Symbol przekreślonego kosza na śmieci umieszczany na sprzęcie, opakowaniu lub dokumentach do niego dołączonych oznacza, że produktu nie wolno wyrzucać łącznie z innymi odpadami. Zużyty sprzęt może zawierać substancje posiadające właściwości trujące i rakotwórcze, niebezpieczne dla zdrowia i życia ludzi, ponadto zatruwające glebę oraz wody gruntowe. Obowiązkiem użytkownika jest przekazanie zużytego sprzętu do wyznaczonego punktu zbiórki w celu właściwego jego przetworzenia. Więcej informacji na temat punktów utylizacji urządzeń można uzyskać od władz lokalnych, firm utylizacyjnych oraz w miejscu zakupu tego produktu.

Gospodarstwo domowe spełnia ważną rolę w przyczynianiu się do ponownego użycia i odzysku surowców wtórnych, w tym recyklingu, zużytego sprzętu. Na tym etapie kształtuje się postawy, które wpływają na zachowanie wspólnego dobra jakim jest czyste środowisko naturalne.

Urządzenie zawiera wbudowany akumulator litowo-jonowy, który nie jest przeznaczony do samodzielnej wymiany.

Po zakończeniu okresu użytkowania urządzenia akumulator zostanie bezpiecznie usunięty przez autoryzowany punkt zbiórki lub serwis.



Symbole umieszczone na urządzeniu i akumulatorze przypominają o obowiązku ich selektywnej zbiórki. Zużyte baterie i akumulatory zawierają substancje, które mogą być szkodliwe dla środowiska i zdrowia ludzi. Dlatego nie wolno wyrzucać ich razem z odpadami komunalnymi. Oddanie baterii do specjalnego punktu zbiórki umożliwi ich bezpieczne przetworzenie i odzyskanie cennych surowców, a jednocześnie zapobiega zanieczyszczeniu gleby, wody i powietrza. Producent ograniczył zawartość substancji niebezpiecznych w akumulatorze, aby zmniejszyć jego wpływ na środowisko.

Producent: Megabajt Sp. z o.o.

ul. Rydygiera 8, 01-793 Warszawa

e-mail: info@megabajt.com.pl, tel. +48 22 560 73 00

www.megabajt.com.pl

Wyprodukowano w Chinach.



EN**Power bank 80000 mAh****TRABAT47826 PRIME-V8****tracer®****Input/Output Ports**

Rated power: 296W/h

Nominal voltage:

Input: TYPE-C1 5V/3A, 9V/2.22A, 12V/1.67 (max PD20W)

Input: TYPE-C2 5V/3A, 9V/2.22A, 12V/1.67 (max PD20W)

Output: USB-A1 5V/3A, 9V/2.0A, 12V/1.5A, SSCP10V2.25A (QC22.5W)

Output: USB-A2 5V/3A, 9V/2.0A, 12V/1.5A, SSCP10V2.25A (QC22.5W)

Output: USB-A3 5V/3A, 9V/2.0A, 12V/1.5A, SSCP10V2.25A (QC22.5W)

Output: TYPE-C1 5V/3A, 9V/2.22A, 12V/1.67A (max PD20W)

Output: TYPE-C2 5V/3A, 9V/2.22A, 12V/1.67A (max PD20W)

80000mAh QC22.5W + PD20W

Chemical type of battery: Li-Ion (lithium-ion pouch type) 3.7V

Product weight: 1560g

SN: 11/25

Rechargeable battery

Portable type

1. Before the first charging, try to fully discharge the power bank. This will help to effectively calibrate the device's charge level indicator.. It is recommended to repeat this process 2-4 times.

When charging the power bank, use suitable accessories such as a compatible charger and cable. The charger should have a minimum output of 2A. The higher the power (18W, 20W, 24W, 30W), the more efficiently and quickly the battery will charge.

The charging cable is also important — remember that not every cable is designed for charging; most are intended for data transfer.

2. To check the battery charge level, press the button. The number of LEDs/digits on the screen will indicate the current battery level.

3. If the product supports fast charging (in/out), one of the LEDs will light up in a different color during fast charging. If the battery has a display, a specific icon will appear to indicate fast charging (in/out).

4. To properly charge the power bank, connect the cable with the correct plug to one of the "input" ports.

To charge an external device (e.g., a phone), connect one end of the charging cable to one of the "output" ports of the power bank and the other end to the charging port of the device you wish to charge.

SAFETY NOTICE, CAUTION:

1. The portable powerbank has a high-quality battery cell that guarantees comfortable and long use.

2. It is suggested that the user use a standard DC 5V power supply.

3. If there is a battery swelling phenomenon and you can see a bulge on the case, stop using the product unconditionally and contact the service center immediately.

4. Do not throw the device, open the housing, do not disassemble the housing elements, do not expose the device to puncture. Do not expose to fire, high temperatures, moisture and water.

5. It is recommended to periodically charge the device (at least once every 4 months) to maintain the life of the battery cells.

Warning. Be sure to follow the safety instructions above, otherwise the device may cause fire, explosion or other damage.



The symbol of a crossed-out wheeled bin placed on electronic or electrical equipment, its packaging or accompanying documents means that the product may not be thrown out together with other waste. Used equipment may contain substances with toxic and carcinogenic properties, hazardous to human health and life, and poisoning the soil and groundwater. It is the user's responsibility to hand over the used equipment to a designated collection point for its proper processing. For more information on recycling of electronic and electrical equipment, please contact your local authorities, waste disposal services and the place where you purchased this product.

The household plays an important role in contributing to the reuse and recovery of secondary raw materials, including recycling, waste equipment. At this stage, attitudes are formed that affect the preservation of the common good, which is a clean natural environment.

The device contains a built-in lithium-ion battery that is not designed to be replaced by the user.

At the end of the device's service life, the battery will be safely disposed of by an authorised collection point or service centre.



The symbols on the device and battery remind you of the obligation to collect them separately. Used batteries and accumulators contain substances that may be harmful to the environment and human health. Therefore, they must not be disposed of with municipal waste. Returning batteries to a special collection point enables them to be safely recycled and valuable raw materials to be recovered, while preventing soil, water and air pollution. The manufacturer has limited the content of hazardous substances in the battery to reduce its impact on the environment.

Producer: Megabajt Sp. z o.o.

ul. Rydygiera 8, 01-793 Warszawa

email: info@megabajt.com.pl, phone: +48 22 560 73 00

www.megabajt.com.pl

Made in China

